

TVs 100	975 - 1000	2000	410
TVs 120	1175 - 1200	2000	510




🇸🇮 NAVODILO ZA SESTAVO
🇭🇷 UPUTSTVO ZA MONTAŽU
🇬🇧 MOUNTING INSTRUCTIONS






TV2DS PULSAR 100, 120





LEVA / LEFT




DESNA / RIGHT







LEVA / LEFT







-2-



-b-




-c-



-4-






-d-



4 x
Ø 4 x 40

4 x
Ø 4 x 40


L1925







-5-

-e-


Zgoraj
Up



Ø 11



Spodaj
Down



-6-

